



INSTALLATION INSTRUCTIONS

Part Number: 85-0400 Holley 4150/4160 K&N® Stubstack®

This K&N® Stubstack® is designed to be used on Holley square bore 4150/4160 model carburetors that have the choke horn milled off, but still require the use of an air cleaner.

This K&N® Stubstack® eliminates the need for hand polishing and radius work. The K&N® Stubstack® will work with all K&N® Custom Chrome Racing Air Cleaners, including the Tall Velocity Stack Air Cleaners.

INSTALLATION:

1. Put the air cleaner base plate on the carburetor.
2. Slide the K&N® Stubstack® onto the center stud and seat it onto the carburetor.
3. Thread a nylon locking nut or a nut with Loctite down snug on the K&N® Stubstack®.
Note: DO NOT OVER TIGHTEN!
4. Install the rest of the air cleaner assembly.