



Part Number 57-0477 INSTALLATION INSTRUCTIONS

Audi TT 1.8L 20V Turbo 180 bhp 1999 On...

1. Unclip and remove the electrical plug from the MAS (Mass Air Sensor). (Fig. 1)
2. Unclip and remove the intake hose from the MAS. (Fig. 2)
3. Carefully remove the air box lid by unscrewing the two screws and disconnecting the auxiliary air pump hose from the side of the lid. (Fig. 3)
4. Carefully remove the MAS from the air box lid. (Fig. 4)
5. Remove the air box base from the vehicle. (two bolts and one nut) (Fig. 5)
6. Refit the MAS into the original intake hose and tighten the hose clip. Make sure the arrow on the MAS, that shows the airflow direction is pointing towards the engine. (Fig. 6)
7. Reconnect the electrical plug to the MAS. (Fig. 7)
8. Carefully fit the new filter element onto the MAS. Tighten the clip until the filter just turns, then tighten the clip one full turn (360 degrees). **No more, do not overtighten the clip!** (Fig. 8)
9. Using the original air box mounting screw, bolt the bracket to the top air box mounting. (Fig. 9)
10. Fix the bracket to the stud on the filter lid using the nut and spring washer supplied. (Fig. 10)
11. Carefully remove the left front lower grille and separate the two parts of the grille. (Fig. 11)
12. Expand the cold air hose. Pierce/drill a 3mm hole in one of the sleeves. Feed the cold air hose up through the left front lower grille along the battery. Secure the bottom end with a plastic tie supplied. (Fig. 12)
13. Replace the open part of the grille.
14. Position the end of the cold air hose to finish approximately 10cm/4" away from the filter element. (Fig. 13)
15. Carefully remove the end of the auxiliary air pump hose. (Fig. 14) *To carry out instruction 15, it may be necessary to gently warm the end piece.*
16. Fit the new breather filter into the air pump hose and secure using the # 20 hose clip supplied. (Fig. 15)
17. Secure the air pump hose using a long plastic tie supplied. (Fig. 16)
18. Carry out a final height / alignment check of the kit, installation is now complete.

Parts list:

- 1 x Filter Element.
- 1 x # 48 Hose Clip.
- 1 x Mounting Bracket.
- 1 x Cold Air Hose Assembly.
- 1 x Breather Filter.
- 1 x Literature Pack.
- 1 x Fixing Kit :-
 - 1 x # 16 Hose Clip.
 - 1 x Flat Metal Washer.
 - 3 x Long Plastic Ties.
 - 1 x Nut Nylock M6.

WARNING: Before starting the engine carry out a final fitment check of the K&N performance kit. It will be necessary for all intake systems to be checked periodically for realignment, clearance and tightening of all connections. Failure to follow the above instructions or proper maintenance may void the warranty.



Fig. # 1



Fig. # 2



Fig. # 3



Fig. # 4



Fig. # 5



Fig. # 6



Fig. # 7



Fig. # 8



Fig. # 9



Fig. # 10



Fig. # 11



Fig. # 12



Fig. # 13



Fig. # 14



Fig. # 15



Fig. # 16

