



# INSTALLATION INSTRUCTIONS

## Part Number: HA-3521

This filter fits: SEE CATALOG FOR CURRENT APPLICATIONS

Congratulations, you have purchased the finest air filter that money can buy. With proper care, this filter will last 1 million miles or more. This filter can be used in a stock machine, with no modifications required. If any engine modifications have been made tuning/jetting adjustments may be required. There are special installation instructions, so please follow the procedures outlined below to ensure the K&N® Filtercharger® seals properly.

**If you need any assistance please call 1-800-858-3333 to speak with a representative in our Customer Service Center before returning the product.**

### INSTALLATION:

- 1.) Remove the 7 screws to gain access to the stock air filter. (Fig.1)
- 2.) Remove the 3 screw that holds the stock air filter in housing & remove filter. (Fig.2)
- 3.) Clean all sealing surfaces in the air box.
- 4.) Apply the supplied spacers onto the dirty side (logo side) as shown. (Fig.3)
- 5.) Install the K&N air filter into housing & tighten the 3 screws to secure the K&N air filter. (Fig.4)
- 6.) Install the housing lid & tighten all 7 screws to complete installation.

**THESE INSTRUCTIONS MUST BE FOLLOWED EVERY TIME THE FILTER IS SERVICED, OTHERWISE THE FILTER MAY NOT SEAL, AND DAMAGE TO THE ENGINE COULD RESULT.**



Fig. 1



Fig. 2



Fig. 3



Fig. 4

### CLEANING:

K&N Engineering, Inc., suggests checking the air filter element periodically for excessive dirt build-up. Depending on your driving conditions, we recommend cleaning your air filter every 50,000 miles. To clean and re-oil, purchase our filter Recharger® service kit, part number 99-5050 or 99-5000 and follow the easy instructions.