



# INSTALLATION INSTRUCTIONS

## Part Number: TB-7617

This filter fits: SEE CATALOG FOR CURRENT APPLICATIONS

\* FREE K&N® decal To register your warranty, please see us online at [knfilters.com/register](http://knfilters.com/register). FREE K&N® decal \*

Congratulations, you have purchased the finest air filter that money can buy. With proper care, this filter will last 1 million miles or more. This filter can be used in a stock machine, with no modifications required. If any engine modifications have been made tuning/jetting adjustments may be required. There are special installation instructions, so please follow the procedures outlined below to ensure the K&N® Filtercharger® seals properly.

**If you need any assistance please call 1-800-858-3333 to speak with a representative in our Customer Service Center before returning the product.**

### INSTALLATION:

1. Remove the stock air filter from the air box. (Fig. 1)
2. Install the K&N® filter into the air box with the K&N® logo facing the velocity stacks. (Fig. 2 & 3)
3. Re-install the air box lid carefully aligning filter seal with receiving channels to complete installation. (Fig. 4 & 5)
4. With the K&N® air filter installed, clean an area on the air box and apply K&N® Stop Decal. The decal will help notify others that this is a reusable air filter.

**THESE INSTRUCTIONS MUST BE FOLLOWED EVERY TIME THE FILTER IS SERVICED, OTHERWISE THE FILTER MAY NOT SEAL, AND DAMAGE TO THE ENGINE COULD RESULT.**



Fig. 1



Fig. 2




Fig. 3



Fig. 4



Fig. 5

### CLEANING:

K&N® Engineering, Inc., suggests checking the air filter element periodically for excessive dirt build-up. Depending on your driving conditions, we recommend cleaning your air filter every 50,000 miles. To clean and re-oil, purchase our filter Recharger® service kit, part number 99-5050 or 99-5000 and follow the easy instructions.