INSTALLATION INSTRUCTIONS Part Number: HA-1016 This filter fits: SEE CATALOG FOR CURRENT APPLICATIONS

* FREE K&N[®] decal To register your warranty, please see us online at knfilters.com/register. FREE K&N[®] decal *

Congratulations, you have purchased the finest air filter that money can buy. With proper care, this filter will last 1 million miles or more. This filter can be used in a stock machine, with no modifications required. If any engine modifications have been made tuning/jetting adjustments may be required. There are special installation instructions, so please follow the procedures outlined below to ensure the K&N Filtercharger[®] seals properly.

If you need any assistance please call 1-800-858-3333 to speak with a representative in our Customer Service Center before returning the product.

INSTALLATION:

- 1. Remove the screw set from the stock filter. (Fig. 1)
- NOTE: The K&N air filter utilizes all existing hardware.
- 2. Insert screw set on K&N® filter. (Fig. 2 & 3)
- 3. Install the K&N[®] filter and tighten the screw set on the air box. (Fig. 4)
- 4. Install air box lid.

THESE INSTRUCTIONS MUST BE FOLLOWED EVERY TIME THE FILTER IS SERVICED, OTHERWISE THE FILTER MAY NOT SEAL, AND DAMAGE TO THE ENGINE COULD RESULT.




Fig. 1





Fig. 3

Fig. 2



Fig. 4

CLEANING:

K&N Engineering, Inc., suggests checking the air filter element periodically for excessive dirt build-up. Depending on your driving conditions, we recommend cleaning your air filter every 50,000 miles. To clean and re-oil, purchase our filter Recharger[®] service kit, part number 99-5050 or 99-5000 and follow the easy instructions.